



Notebook Screen Cleaner – DMAM300

INSTRUCTION SHEET

CONGRATULATIONS

Congratulations on the purchase of the GADGET GEEK Notebook Screen cleaner. We have taken great effort to deliver you the safest and best possible solution for your LCD screen to provide you improved viewing pleasure.



INSTRUCTIONS:

It's easy to look after your notebook or monitor and keep it clean and clear of dust, dirt and fingerprints. Simply follow the instructions below:

Directions for use:

1. Spray a light amount of cleaning solution onto the screen (do not soak the screen)
2. Clean the screen with the micro fibre cloth using side to side strokes.

Note:

- Allow the cloth to dry after use.
- Wash cloth with water only. Do not use detergent or fabric softener.

PRODUCT INFORMATION:

For more product information and updates on the Gadget Geek range visit www.gadgetgeek.biz